



1. Uncrew 4 screws on the side



2. Unplug 6 white connectors (remember the order)



3. If necessary uncrew green wire.



4. Check the sd card – red square
5. For take out of the SD card, 4 screws in green circle needs to be uncrewed with caution

